



SIDING ESTIMATOR

| NET SQ. FT. | 1/2X6 B/F | 1/2X8 B/F | 3/4X10 B/F |
|----------------|--------------|--------------|---------------|
| 1200 | 1600 | 1476 | 1416 |
| 1250 | 1667 | 1538 | 1475 |
| 1300 | 1734 | 1599 | 1534 |
| 1350 | 1800 | 1661 | 1593 |
| 1400 | 1867 | 1722 | 1652 |
| 1450 | 1934 | 1784 | 1711 |
| 1500 | 2000 | 1845 | 1770 |
| 1550 | 2067 | 1907 | 1829 |
| 1600 | 2134 | 1968 | 1888 |
| 1650 | 2200 | 2030 | 1947 |
| 1700 | 2267 | 2091 | 2006 |
| 1750 | 2334 | 2153 | 2065 |
| 1800 | 2400 | 2214 | 2124 |

TO ESTIMATE B/F (BOARD FEET)

1. Multiply perimeter by height to eaves.
2. Add gable area (multiply 1/2 distance from wall at eaves to peak by width).
3. Subtract square footage of opening (doors, windows, etc.).
4. Refer to table above for estimated B/F. Or multiply net square feet by siding factor...
1/2x6: 1.33, 1/2x8: 1.23, 3/4x10: 1.18.

NOTE: One inch lap has been used for above figures.
No additional footage has been included for "trim" waste.